

# To Install SIS 2011A DVD Software

To install & use SIS DVD software, 4 steps are required  
**Administrative Rights are REQUIRED to install the SOFTWARE – not the data**

- I. Install SIS Software
- II. Install SIS DATA Setup CD
- III. License SIS Software
- IV. Create/Import SIS User Accounts

**Instructions for SIS 2011A (released 05/11)**  
Valid data is April 2011 and later (until next Software release)

- I. **Install the software** (accept license agreement)
  - a. Install from either STW DVD\SIS Folder or SIS standalone DVD (setup.exe)
    - i. Choose language
    - ii. Continue by clicking   
InstallShield Wizard appears prompting graphic plug-ins install
    - iii. Continue by clicking   
InstallShield Wizard appears prompting SIS install
    - iv. click
    - v. Read and accept License Agreement  
I accept the terms of the license agreement.
    - vi. Validate configuration settings
  - b. Install of software complete
    - i. Receive instructions regarding:  
Run Setup DVD - Reboot before using SIS -
- II. **Install SIS Data Setup** (RERR0010-XX & RERR0011-XX) & Reboot
  - a. Install – either by auto-run or selecting Start->Run->Setup from CD drive
  - b. Step through install screens (this will happen for both data discs)  
Language - Welcome - Finish
  - c. Repeat steps a and b for the second data disc
  - d. Upon completion of the second data disc, reboot
- III. **Start SIS – Receive License Screen** (for new installs only)  
Authorized Cat Dealers have access to on-line licensing  
Customers need to work through their dealers
  - a. Select & Copy the license code from the License Screen
  - b. Logon to on-line licensing
  - c. Select NEW SIS DVD/Network
  - d. Complete User Registration Information
  - e. Paste License Code to on-line licensing
  - f. Select & Copy License Key from Subscription Details on  
<https://dealersoftwarelicensing.cat.com>
  - g. Switch back to SIS
  - h. Paste License Key into License Screen in SIS software
  - i. Authorize
  - j. Receive “License Granted Successfully” message

#### **IV. Setup New Users – (new installs only)**

- a. Login to SIS User Administration **Note: Profiles must exist prior to Adding Users**
  - b. Profile maintenance
    - Add profile and complete information
  - c. User Administration
    - Add user and complete information
  - d. Import users
    - i. XML file required from SIS Administrator
    - ii. Use Import when users have been exported
    - iii. Customers to contact Dealer
    - iv. Create user name and password if no Imported Users are available,
    - v. Browse & Load
    - vi. User names showing in red already exist on the computer
    - vii. Select users to be imported by checking box
- V. Logon to SIS at User Login Screen
- VI. Accept License Agreement

# Hardware & Software Requirements

2011 SIS System Requirements - PC/Laptop Configurations			
	<u>Web and Network Client</u>	<u>DVD</u>	<u>Network Server</u>
<b>Operating System*</b>	Windows XP (32 bit) Windows Vista (32 bit) Windows 7 (32 bit and 64 bit)	Windows XP (32 bit) Windows Vista (32 bit) Windows 7 (32 bit and 64 bit)	Windows Server 2003 or 2008
<b>Web Browser*</b>	Microsoft Internet Explorer, Version 7.0 and 8.0	Microsoft Internet Explorer, Version 7.0 and 8.0	Microsoft Internet Explorer, Version 7.0 and 8.0
<b>Processor Speed*</b>	2.0 GHz Pentium-compatible processor or higher	2.0 GHz Pentium-compatible processor or higher	2.0 GHz Pentium-compatible processor or higher
<b>RAM Required</b>	2GB	2GB	2GB
<b>Free Hard Disk Space</b>			
2011	N/A	<b>16 GB for SIS (Refer to Microsoft for recommended free hard disk space for Operating System)</b>	<b>16 GB for SIS (Refer to Microsoft for recommended free hard disk space for Operating System). DVD Tower or 150 GB Hard Disk Storage (To maintain DVD library)</b>
Note - SIS hard disk space estimates include additions of 2D hot-pointed and 3D graphics in 2010, 2011 and additional data growth installed on user PCs/Laptops. The remainder of SIS data continues to reside on DVD libraries.			
<b>DVD Drive</b>	N/A	Third generation DVD drive (required) Note: Capability to read dual layer DVDs.	Third generation DVD drive (required) Note: Capability to read dual layer DVDs.
<b>Video Capability</b>	Monitor capability of supporting 1024 x 768 resolution and Open GL supported Graphics Card (Recommend 128MB+ RAM)	Monitor capability of supporting 1024 x 768 resolution and Open GL supported Graphics Card (Recommend 128MB+ RAM)	Monitor capability of supporting 1024 x 768 resolution and Open GL supported Graphics Card (Recommend 128MB+ RAM)
<b>SIS Helper Applications and Plug-ins</b> <b>Note: Instructions for installations are included in the SIS installation and the Downloads screen in SIS.</b>	Adobe Systems Inc. Acrobat Reader (Version 9.0 required to view Interactive Schematics) LizardTech, Inc. DjVu Arbortext IsoView PTC ProductView Express Lite Java plug-in and SISJwAPI executable	Adobe Systems Inc. Acrobat Reader (Version 9.0 required to view Interactive Schematics) LizardTech, Inc. DjVu Arbortext IsoView PTC ProductView Express Lite Java plug-in and SISJwAPI executable	Adobe Systems Inc. Acrobat Reader (Version 9.0 required to view Interactive Schematics) LizardTech, Inc. DjVu Arbortext IsoView PTC ProductView Express Lite Java plug-in and SISJwAPI executable
<b>*Derived from current CITA (Caterpillar Information Technology Architecture) standards and are subject to change upon changes mandated by CITA.</b>			

**The system requirements must be met for users to efficiently utilize SIS software. If system requirements are not met, there will be performance issues such as delayed content loading, increased durations for installations, and inability to view and interact with new graphic types.**